

Ubuntu Support Matrix for Dell EMC PowerEdge Servers		
<p>Ubuntu is Canonical-tested and Canonical-supported. Dell works closely with on-site Canonical engineers to ensure enablement and validation. Dell will handle hardware issues but pass on OS-related issues to Canonical.</p> <p>For full details visit Canonical's Hardware Compatibility List at:  <a href="https://certification.ubuntu.com/server/models/?vendors=Dell%20EMC">https://certification.ubuntu.com/server/models/?vendors=Dell%20EMC</a>            Or select a hyperlink below:</p>		
PowerEdge 14th Generation Servers	Ubuntu Server 16.04 LTS x86_64	Ubuntu Server 18.04 LTS x86_64 (Coming in 2018)
Rack Servers		
<p>* Ubuntu 16.04.1,2, and 3 do not contain inbox drivers for; PERC10 – H740p, H840 Qlogic NIC's – QL41264, QL41164, QL41262            These components will not be supported with Ubuntu until 16.04.4</p>		
<a href="#">R740</a>	16.04.1 LTS	
<a href="#">R740xd</a>	16.04.1 LTS	
<a href="#">R640</a>	16.04.1 LTS	
<a href="#">R940</a>	16.04.2 LTS	
PowerEdge C		
<a href="#">C6420</a>	16.04.1 LTS	

Note the change in column headings below, not the same as above:

Ubuntu Support Matrix for Dell EMC PowerEdge Servers		
<p>Ubuntu is Canonical-tested and Canonical-supported. Dell works closely with on-site Canonical engineers to ensure enablement and validation. Dell will handle hardware issues but pass on OS-related issues to Canonical.</p> <p>For full details visit Canonical's Hardware Compatibility List at:  <a href="https://certification.ubuntu.com/server/models/?vendors=Dell%20EMC">https://certification.ubuntu.com/server/models/?vendors=Dell%20EMC</a>            Or select a hyperlink below:</p>		
PowerEdge 13th Generation Servers	Ubuntu Server 14.04 LTS x86_64	Ubuntu Server 16.04 LTS x86_64
Rack Servers		
<a href="#">R730</a>	14.04.1 LTS	16.04 LTS
<a href="#">R730xd</a>	14.04.1 LTS	16.04 LTS

<a href="#">R630</a>	14.04.1 LTS	16.04 LTS
<a href="#">R930</a>	14.04.1 LTS	16.04 LTS
<a href="#">R530xd</a>		16.04 LTS
<a href="#">R530</a>	14.04.1 LTS	16.04 LTS
<a href="#">R430</a>	14.04.1 LTS	16.04.2 LTS
<a href="#">R330</a>	14.04.1 LTS	
<a href="#">R230</a>	14.04.1 LTS	
<b>Blade Servers</b>		
<a href="#">M630</a>	14.04.1 LTS	
<a href="#">M830</a>	14.04.2 LTS	
<b>Tower Servers</b>		
<a href="#">T630</a>	14.04.1 LTS	16.04.1 LTS
<a href="#">T430</a>	14.04.1 LTS	
<a href="#">T330</a>	14.04.4 LTS	16.04.1 LTS
<a href="#">T130</a>	14.04.4 LTS	
<a href="#">T30</a>		16.04.1 LTS
<b>Converged Platforms</b>		
<a href="#">FC430</a>	14.04.2 LTS	
<a href="#">FC630</a>	14.04.1 LTS	16.04.1 LTS
<a href="#">FC830</a>	14.04.1 LTS	
<a href="#">FM120</a>	14.04.1 LTS	
<b>PowerEdge C</b>		
<a href="#">C6320</a>	14.04.2 LTS	16.04.1 LTS

<b>PowerEdge 12th Generation Servers</b>	<b>Ubuntu Server 14.04 LTS x86_64</b>	<b>Ubuntu Server 16.04 LTS x86_64</b>
<b>Rack Servers</b>		
R720	14.04 LTS	
R720XD	14.04 LTS	16.04 LTS
R620	14.04 LTS	
R820	14.04 LTS	
R920	14.04 LTS	
R220	14.04 LTS	
R320	14.04 LTS	
R420	14.04 LTS	
R520	14.04 LTS	
<b>Blade Servers</b>		
M520	14.04 LTS	
M620	14.04 LTS	
M820	14.04 LTS	

M420	14.04 LTS	
<b>Tower Servers</b>		
T620	14.04 LTS	
T320	14.04 LTS	
T420	14.04 LTS	
<b>PowerEdge C</b>		
C6220	14.04 LTS	
C6220ii	14.04 LTS	
C8220	14.04 LTS	
C8220X	14.04 LTS	
C8220XD	14.04 LTS	